

# AA402 M12 EYEBOLT ANCHOR

## INSTALLATION INSTRUCTIONS



### Things To Know:

AA402 is designed for installation in concrete and structural steel. It has been specifically developed for applications in rope access (abseiling) and it can be also used to support a fall arrest load of 15 kN provided a suitable personal shock absorber is used.

### Anchor Rating:

The AA402 eyebolt has been independently tested in accordance with AS/NZS 5532:2025 and verified as a 15 kN rated rope access/fall arrest anchorage device.

### Fixing Options:

Use only approved chemsets or M12 mechanical anchors meeting the required performance criteria.

- Suitable for cracked and non-cracked concrete
- Minimum embedment 110mm for chemical anchors

### Examples Include:

- Chemical HILTI HVU2 M12 (HOLE 14 DIA) using SRA setting tool
- Chemical Hilti HIT or Hilti RE 500 (HOLE 14 DIA) or equivalent
- Hilti HSL 3 M12 and HSL 3B M12 (HOLE 18 DIA)
- Through bolt M12 (HOLE 14 DIA)

### Concrete Specifications:

Min. concrete strength: 25 Mpa

Min. slab thickness: 150 mm

Min. distance to edge: 200 mm

Min. distance to another anchor: 200mm

### Note:

Edge distances less than the stated minimum may be permitted where verified by anchor manufacturer design (e.g. Hilti). Verification must be based on project-specific parameters including concrete strength, embedment depth, anchor size, and edge condition, with documented capacity calculations.

### Loading:


Load the eye bolt in shear, not exceeding 20° with the surface it's installed into unless installed as a through bolt in steel.

### Tools Needed for Installation:


Rotary hammer drill, masonry drill bit 14 or 18 (for Hilti HSL), air pump, cleaning brush, SRA setting tool if using Hilti HVU chemset, chemical dispenser gun if using injectable chemset

### Installation Steps – M12 Hilti HVU chemset in concrete:


1. Use Hilti Reo Scan or similar device to avoid drilling the steel reinforcement in concrete.
2. Mark the position for hole to be drilled.
3. Drill a DIA 14mm x 110mm hole. Ensure the hole is 90° with the drilled surface.




4. Clean the hole 3 times with compressed air and cleaning brush.



5. Insert one Hilti HVU M12 chemical pack in the hole.



6. Using a rotary hammer with SRA setting tool, install the AA402 eyebolt



7. Allow sufficient drying time as per Hilti HVU instructions.

### Installation Steps – Hilti HIT or Hilti RE-500 or equivalent chemset in concrete:

1. Use Hilti Reo Scan or similar device to avoid drilling the steel reinforcement in concrete.
2. Mark the position for hole to be drilled.
3. Drill a DIA 14mm x 110mm hole. Ensure the hole is 90° with the drilled surface.
4. Clean the hole 3 times with compressed air and cleaning brush.
5. Inject Hilti HIT or RE 500 or equivalent chemical in the hole as per the manufacturer's instructions.
6. Install AA402 by turning it slowly in anti-clockwise direction while pushing it inside the hole. Wipe off the excess chemical and smooth it around the eyebolt like a silicon bead.
7. Allow sufficient drying time as per the chemical manufacturer's instructions.

### Installation Steps – M12 Hilti HSL-3 and HSL-3B in concrete:

1. Use Hilti Reo Scan or similar device to avoid drilling the steel reinforcement in concrete.
2. Mark the position for hole to be drilled.
3. Drill one DIA 18 mm x 125mm hole. Ensure the hole is 90° with the drilled surface.
4. Clean the hole 3 times with compressed air and cleaning brush.
5. Install Hilti HSL-3B or HSL-3B and use a torque wrench as per Hilti instructions.
6. Remove the M12 bolt inside the HSL-3 or HSL-3B and install AA402 eyebolt instead.

### Installation Steps – M12 through bolt:

1. Use Hilti Reo Scan or similar device to avoid drilling the steel reinforcement in concrete.
2. Mark the position for hole to be drilled.
3. Drill one DIA 14mm through hole. Ensure the hole is 90° with the drilled surface.
4. Install AA402 with one backing plate (BP2 or BP3) on the back side.
5. Clamp down with a M12 washer and lock nut and tighten fully. Ensure minimum of 5 threads are showing when fully tightened.

### Proof Load and Certification:

All glued in and friction anchorages must be proof loaded before their initial use and subsequently on regular basis to satisfy the requirements set out in AS/NZS 1891.4:2025 and ISO 22846 (2020).

- Proof load the eye to 7.5 kN for all applications in rope access and fall arrest
- Through bolts must be visually inspected – do not proof load!

### Note:

The roof structure must be assessed by a structural engineer unless it is clear to a suitably qualified person that it is capable of withstanding the forces imposed on it during arresting of a fall and during work positioning.

### **Disclaimer:**

*All product specifications and technical descriptions, recommendations and other information provided in this document are given as general guidance and advice, and are to be considered in conjunction with Safety Roof Anchors installation instructions and any other data available and applicable to each particular standard product or system. Use of such data is however the user's sole responsibility taking into account the intended application and actual conditions existing on the specific worksite. Consequent selection of the right product for any particular use remains the user's ultimate responsibility.*

*Safety Roof Anchors is therefore not obligated or liable for any direct or indirect, incidental or consequential damages, losses or expenses in connection with, or by reason of the suitability and use of or otherwise, any product or system for any purpose. Implied warranties of merchantability or fitness for any particular purpose are specifically excluded. Safety Roof Anchors maintains a policy of continuous improvement and development, and therefore reserves the right to modify, amend or otherwise alter product and system designs and specification, models and part numbers, colours and pricing etc., without prior notice. Safety Roof Anchors accepts no liability whatsoever for incorrect information, errors or omissions.*